

PART NO.	NO. REQ'D PER TRACTOR	ITEM	LIST P
-------------	-----------------------------	------	--------

C H A S S I S A N D F R A M E

CF-1	2	FRONT AXLE ASSEMBLY (SPINDLE AND SHAFT)	\$ 14.6
CF-2	2	FRONT WHEEL AXLE SHAFT INSIDE SPACERS	.2
CF-3	2	FRONT WHEEL AXLE COLLARS	.1
CF-4	4	FRONT AXLE ASSEMBLY BRONZE BUSHINGS	.2
CF-5	1	FRONT AXLE TIE BAR	1.1
CF-6	1	FRONT AXLE STEERING CONNECTING ROD	1.1
CF-7	1	FRONT AXLE T-CROSS BAR ASSEMBLY	9.1
CF-8	2	FRONT AXLE ALEMITE GREASE FITTINGS	.1
CF-9	3	FRONT AXLE ASSEMBLY BOLTS AND NUTS	.1
CF-10	2	MOTOR BLOCKS (FOR WISCONSIN AND LAUSON ENGINES ONLY)	2.1
CF-11	1	STEERING WHEEL	4.1
CF-12	1	STEERING COLUMN SHAFT	2.1
CF-13	1	STEERING COLUMN BASE ASSEMBLY	4.1
CF-14	1	STEERING COLUMN CAST IRON WHEEL CAP	.1
		STEERING COLUMN ADJUSTING COLLAR (STEEL)	1.1
CF-15	1	IMPLEMENT LIFT HANDLE ASSEMBLY	9.1
CF-16	1	IMPLEMENT LIFT RUBBER HANDLE GRIP	.1
CF-17	1	IMPLEMENT LIFT CONNECTING SHAFT PIN	2.1