



INSTRUCTIONS FOR MOUNTING AND ADJUSTING TIGER TRACTOR HAND CRANK NINE (9") AND TEN (10") PLOWS

- (1) FOR DEPTH ADJUSTMENT - TO PLOW DEEPER TURN HAND CRANK TO RIGHT IN CLOCKWISE DIRECTION. (RECOMMEND DEEP ADJUSTMENT FOR FIRST 2 FURROWS THEN ADJUST AS DESIRED.)
- (2) TO PLOW SHALLOW - TURN HAND CRANK TO LEFT IN COUNTER CLOCKWISE DIRECTION.
- (3) TO RAISE OR LOWER COULTER - LOOSEN SET SCREWS (X) AND (Y) AND ADJUST TO DESIRED LEVEL.

TIGER TRACTOR CORPORATION
KEYSER, WEST VIRGINIA

America's Finest Small Tractor

For travel over exceptionally rough terrain, raise plow to maximum extreme height by turning handcrank to right (clockwise direction) as far as screw threads permit.